KARATE CHAMP INSTRUCTIONS

2 PLAYER VERSION





KARATE CHAMP INSTRUCTIONS

1. TRAINING

- To learn moves, practice as instructed by arrows shown at bottom of screen.
- LEFT JOYSTICK controls player's direction of movement.
- = RIGHT JOYSTIC controls player's choice of attack.
- BOTH must be used together to execute different moves.

2. MATCH

- Player 1 controls WHITE PLAYER, Player 2 controls RED PLAYER.
- Move joystick to execute the various moves (see Move Chart).

3. BONUS INTERVAL

- After each match, play bonus rounds to score additional points.


MOVE CHART

| Left Lever | Right Lever | + Neutral | White Player H Red Player | White Player | † Up | Down |
|-----------------|----------------|----------------------|-----------------------------|-----------------------------|---------------------------------|------------------|
| Ne | tral | | Back Kick | Front Kick Reverse Punch | Round Kick | Low Kick |
| White Player | Red Player | Move Back Defense | Back Kick | Back Round Kick | Upper Punch | Low Kick |
| White Player | Red Player | Move Forward | Turn Back Kick | Lunge Punch Front Kick | Upper Lunge Punch Round Kick | Low Kick |
| | f Jp | Jump | Jumping Back Kick | Jumping Side Kick | Back Flip Kick | Front Flip Kick |
| Down | | Lower | Back Foot Sweep | Front Foot Sweep | Lower Reverse Punch | Front Foot Sweep |

1. HARNESS CONNECTION

1) Terminal Numbering CR7E-44DA-3.96E (HIROSE) 3.96mm Pitch





A B C D E F H J K L M N P R S T U V W X Y Z

2) Signals to Terminal

Connector CN2 CR7E-44DA-3.96E

| Pin No. | Signal | Pin No. | Signal | | |
|---------|----------------|---------|----------------|--|--|
| 1 | 1P RIGHT DOWN | A | 2P RIGHT DOWN | | |
| 2 | 1P RIGHT UP | В | 2P RIGHT UP | | |
| 3 | 1P RIGHT LEFT | C | 2P RIGHT LEFT | | |
| 4 | 1P RIGHT RIGHT | D | 2P RIGHT RIGHT | | |
| 5 | 1P LEFT DOWN | Е | 2P LEFT DOWN | | |
| 6 | 1P LEFT UP | F | 2P LEFT UP | | |
| 7 | IP LEFT LEFT | Н | 2P LEFT LEFT | | |
| 8 - | 1P LEFT RIGHT | J | 2P LEFT RIGHT | | |
| 9 | | K | | | |
| 10 | | Ŀ | | | |
| 11 | 1P SELECT | M | 2P SELECT | | |
| 12 | COIN 1 | N | COIN 2 | | |
| 13 | COIN COUNTER 1 | P | COIN COUNTER 2 | | |
| 14 | TV. B | R | TV. G | | |
| 15 | SYNC | S | TV. R | | |
| 16 | | T _ | | | |
| 17 | SOUND + | U | SOUND - | | |
| 18 | +12V | V | | | |
| 19 | +5 V | W | +5 V | | |
| 20 | +5 V | X | +5V | | |
| 21 | CRT GND | Y | GND | | |
| 22 | GND | Z | GND | | |

2. POWER SUPPLY

| +5V | ±2% | 5A |
|------|-----|------|
| +12V | ±2% | 0.1A |

3. OPERATION ENVIRONMENTS

| | Temperature | Humidity | |
|-----------|--------------|----------|--|
| Operation | 5 ~ 35°C | 20 ~ 80% | |
| Storage | -15 ~ 65°C • | 10 ~ 90% | |

4. CRT MONITOR

(1) Color Signals R.G.B. Separate

Black

$$0 - +2V$$

Image Signal

$$+2.5V - +4V$$

(2) Synchronize Signal Composite

$$0-0.5V$$

$$+3V - +5V$$


(3) Screen Image Size

Image can be shrunk both horizontally and vertically by 10%. Adjust monitor to widen the screen image.


5. DIMENSION

 $NOI-80 \rightarrow 230mm \times 310mm$

 $NRI-80 \rightarrow 230mm \times 310mm$




CONNECTOR DFV-01 CR7E-44DE-3.96E (CN-2)



6. MONITOR CONNECTION PCB NOI-80


Monitor input composite signals — Horiz/Vert on +5V can be connected. Circuit diagram of each signal shown below.



7. EXAMPLE OF STANDARD CONNECTION


PCB NOI-80

2 coin switches can be installed.



8. COIN COUNTER - DRIVE CIRCUIT

PCB NOI-80




9. EXAMPLE OF SPEAKER CONNECTION



DIP SWITCH SETTINGS

| | DIP SWITCH | | | | | |
|----|------------|-----|------------|----|----------------------|--|
| NO | SETTINGS | | | | EXPLANATION | |
| 8 | OFF | | ON | | GAME TIME LIMIT | |
| | NORMAL | | FREE GAME | | | |
| 7 | OFF | | ON | | SOUND IN IDLING MODE | |
| 7 | NO | | YES | | | |
| 6 | OFF | OFF | ON | ON | | |
| 5 | OFF | ON | OFF | ON | DIFFICULTY LEVELS | |
| | EAS | Y | →DIFFICULT | | | |
| 4 | OFF | OFF | ON | ON | LEFT | |
| 3 | OFF | ON | OFF | ON | SELECTOR | |
| | 1 | 1 | 2 | 3 | COIN | |
| | 1 | 2 | 1 | 1 | CREDIT | |
| 2 | OFF | OFF | ON | ON | RIGHT SELECTOR | |
| 1 | OFF | ON | OFF | ON | | |
| | 1 | 1 | 2 | 3 | COIN | |
| | 1 | 2 | 1 | 1 | CREDIT | |

4,4



MITTEILUNG ZU KARATE CHAMP II

Sind mehrere Kredite vorhanden und es spielt nur ein Spieler am Gerät, so spielt dieser automatisch gegen den Computer. Hat der Spieler das Spiel verloren, so wird auf dem Monitor optisch abgefragt, ob man weiterhin allein oder zu zweit weiterspielen möchte.

Wählt man weiterhin das Einzelspiel, so fängt man wieder mit dem ersten Bild an.

Entscheidet man sich aber für das Doppelspiel, so werden zwei Kredite abgezogen und die beiden Spieler spielen gegeneinander. Nachdem einer der beiden Spieler verloren hat, wird automatisch ein Kredit abgezogen und beide Spieler starten weiter in einem neuen Bild.

Ist nun kein Kredit mehr vorhanden nachdem ein Spieler verloren hat, so kann dieser, innerhalb der vorgegebenen Zeit, eine Münze nachwerfen und somit weiterspielen.

Geschieht dieser nachträgliche Münzeinwurf nicht, so spielt der Gewinner automatisch alleine gegen den Computer weiter.

Durch den automatischen Kreditabzug beim Doppelspiel kommen beide Spieler in den Genuß bei jedem neuen Kampf vor einer neuen Kulisse zu spielen. Außerdem wird dadurch der Spielfluß beim Doppelspiel nicht behindert.

Im Bedarfsfall ist eine Erweiterung der Spielanleitung abzufordern.